


Operating and maintenance instructions

BLÜCHER Marine® floor drains in stainless steel



Comprising:

Lower parts for welding int decks, type nos. 470 and 475

Upper part for flexible sheet flooring, type no. 473

Upper parts for tiled floors, type nos. 471 and 472

Upper part for epoxy/resin flooring, type no. 472

Upper part for steel decks, type nos. 474 and 620

Water trap, type nos. 502, 505 and 525



For the owner:

BLÜCHER Marine® deck drain in stainless steel AISI 316L or optionally AISI 304 has been installed. The deck drain has been approved by leading international classification societies for use onboard ships and off-shore installations.

Prior to starting use:

- Check that the drain has been cleaned leaving no concrete spills etc.
- Check that the water trap has been installed
- In vinyl floors check that the clamping ring has been well fixed

Normal operation:

BLÜCHER Marine® deck drain in stainless steel has a removable water trap with excellent self-cleansing capabilities. In case of many impurities it may be necessary to clean the water trap at appropriate intervals.

Cleaning:

- Loosen the screws in the grating (2 or 3 screws). Remove the grating and the water trap.
- Clean the water trap with detergent as necessary.
Make sure that lubricant has been applied to the sealing ring of the water trap. Install the water trap applying a light pressure and twisting the water trap down to the stop ring in the drain. To avoid bad odours, make sure that the sealing ring of the water trap fits tightly to the drain.
- Replace the grating and tighten the screws.

Technical data:

Specification of the product range and technical information are available as catalogues.

BLÜCHER UK Ltd.

Station Road Industrial Estate

Tadcaster . North Yorkshire . LS24 9SG

Tel. +44 (0) 1937 838000 . Fax +44 (0) 1937 832454

www.blucher.co.uk . mail@blucher.co.uk